

BACKRACK™

FUNCTION AND STYLE FOR TODAY'S TRUCKS



BACKRACK™

19368528/19368527
19368538 - Shortened



SAFETY RACK

19368529/19368530



STANDARD HARDWARE NO DRILL

- 19368531/19368532
- Meant for use without toolbox
- Includes fasteners



TOOLBOX HARDWARE NO DRILL

- 19368533/19368534
- Meant for use with 21" toolboxes
- Raises toolbox 2"
- Includes fasteners



LOW PRO TONNEAU HARDWARE NO DRILL

- 19368535/19368536
- Meant for use with low profile inside the rail tonneaus
- Meant for use without toolbox
- Includes fasteners



WIDE TOP TONNEAU HARDWARE NO DRILL

- 19368537
- Meant for use with wide top rail covers
- Raises rack 2"
- Meant to be used with shortened rack Part # 19368538
- Includes fasteners



MINI LIGHT BAR BRACKET SOLD SEPARATELY

- 19368541 (Blue) / 19368540 (Amber)
- Dimensions : 3 5/8"H x 16 1/2"W x 8 1/4"D
- Low Profile Permanent Mount



MINI LIGHT BAR BRACKET NO DRILL LIGHT SOLD SEPARATELY

- 19368539
- 16 x 7" Center Mount Base
- Clamps to Flat Bar on Horizontal Assembly
- Hole in center of base to run wiring through
- Light sits in center of cab in front of BackRack™
- Longer Bolts required for use with Safety Rack

> more info at backrack.com



ACCESSORIES

BACKRACK™

FUNCTION AND STYLE FOR TODAY'S TRUCKS

APPLICATION GUIDE

CHOOSE YOUR CAB GUARD FRAME

	BACKRACK™	BACKRACK™ Shortened	SAFETY
CHEVROLET / GMC			
2014-2018 Silverado, Sierra	19368528	19368538	19368529
2015-2018 Colorado / Canyon	19368527	N/A	19368530

CHOOSE YOUR HARDWARE KIT

	STANDARD NO DRILL	TOOLBOX NO DRILL 21"	Low Pro Tonneau	Wide Top Tonneau
CHEVROLET / GMC				
2014-2018 Silverado, Sierra	19368531	19368533	19368535	19368537
2015-2018 Colorado / Canyon	19368532	19368534	19368536	N/A

* See Tonneau Brands Compatibility Chart for more information



HOW TO ORDER

- 1 Determine Year, Make, Model of Truck
- 2 Choose a Frame
- 3 Choose a Hardware Mounting Kit Option
- 4 Dealers order from GM



FRAME



HARDWARE KIT



FINAL ASSEMBLY

more info at backrack.com



ACCESSORIES