

### Advanced Driver Assistance Systems

Part Name	Part Number	COL D Preferred	SILVER Preferred	POWERTRAIN Preferred
LANE KEEP CAMERA	28462			
CONTROL ASSY-INTELLIGENT CRUISE CONTROL	18995			
DISTANCE WARNING SNR SW	25125			
SWITCH ASSY - BSW	25126			
ACC BRAKE HOLD RELAY	25184			
ROUND VIEW MONITOR SWITCH	25308			
SWITCH-STEERING WHEEL, PRO PILOT	25550			
FRONT SONAR SENSOR BUZZER	25659			
BUZZER SONAR SENSOR	25660			
SONAR ROAD SENSOR	25965			
SWITCH-SENSOR OFF, PARKING (SONAR)	25988			
SONAR SWITCH ASSY	25989			
FRONT SONAR SENSOR NS	25993			
REAR SONAR SENSOR NS	25996			
SENSOR-SONAR, FRONT SIDE	25998			
SENSOR-SONAR, REAR SIDE	25999			
BUZZER ASSY-LKS / LDW	26349			
WARRANTY CHIME BUZZER	26350			
BSW/BSW MOTOR	26350			
CONTROL ASSY-BACK VIEW	26362			
RADAR - SW	28405			
UNIT AWM CONTROL	28406			
CONT ASSY CAMERA	28416			
CAMERA ASSY-SIDE VIEW	28419			
VEHICLE DATA TRANSMITTER/ASSY	28420			
BSW CONTROL ASSY	28428			
CONTROL_MODULE - BUZZER, DRIVER ASSISTANT	28429			
SID/OBSTACLE WARNING SENSOR	28430			
BUZZER UNIT-NTM/DE	28430			
SENSOR ASSY - DISTANCE, ICC	28437			
CAMERA ASSY-BACK VIEW	28442			
CAMERA ASSY - LKS / LDW	28443			
CONTROL_MODULE SW	28446			
CAMERA ASSY-FR VIEW	28461			
SOLENOID VALVE ASSY-BACK VIEW CAMERA	28479			
CONTROL ASSY-CAN GATEWAY	28481			
SOLENOID VALVE ASSY - BACK VIEW CAMERA	28499			
REAR SONAR SENSOR, FRONT	28971			
CONTROL UNIT-SONAR SENSOR	28972			
TUBE ASSY - WASHER, REAR VIEW CAMERA	28975			
AWM CAMERA FINISHER	28979			

### AIR CONDITIONER/HEATER

Part Name	Part Number	COL D Preferred	SILVER Preferred	POWERTRAIN Preferred
COMPRESSOR BRACKET	11910			
A/C COMPRESSOR IDLER PULLEY	11924			
IDLER PULLEY	11925			
IDLER PULLEY BRACKET	11926			
RESERVOIR TANK, CAP HEATER	21712			
REAR AIR DUCT-HEATER PRESSURE	22367			
TEMPERATURE SENSOR	22636			
REAR HEATER CONTROL	23207			
BLOWER MOTOR RELAY	25208			
HEATER RELAY	25214			
A/C RELAY	25218			
F.I.C.D. RELAY (Fast Idle Control Device)	25224			
REAR A/C RELAY	25225			
FAN MOTOR RELAY	25246			
MAX COL D DOOR RELAY	25257			
REAR HEATER RELAY	25274			
RELAY - AFS	25295			
CONTROL-REAR HEATER, FRONT	25307			
HEATER UNIT	27000			
REAR HEATER CORE	27013			
REAR HEATER MOTOR	27014			
HEATER & A/C CONTROL	27030			
VACUUM SELECTOR VALVE	27031			
ATC CONTROL	27032			
REAR HEATER	27035			
A/C HARNESS	27038			
A/C SWITCH	27041			
BLOWER CASE/HOUSING	27065			
BLOWER MOTOR & FAN	27070			
HEATER CONNECTOR	27071			
HEATER SWITCH RESISTOR	27077			
VACUUM ACTUATOR	27080			
VACUUM TANK	27084			
VACUUM WATER COCK	27090			
VACUUM CHECK VALVE	27096			
HEATER COCK	27115			
HEATER CODE	27116			
CONTROL CABLE	27134			
MODE ACTUATOR ASSY	27141			
PTC HEATER ASSY	27143			
PTC HEATER ASSY	27144			
PTC HEATER ASSY	27150			
DEFROSTER HOSE	27164			
REAR HEATER RESISTOR	27178			
HEATER HOSE	27181			
HEATER HOSE	27182			
THERMISTOR	27322			
AMPLIFIER-THERMO CONTROL	27330			
REAR BLOWER MOTOR	27375			
FAN IMPELLER	27383			
REAR COOLING UNIT	27405			
REAR EVAPORATOR	27410			
REAR A/C HIGH TUBE ASSY	27413			
REAR A/C LOW TUBE ASSY	27414			
CASE ASSEMBLY	27415			
AIR FILTER CONTROL	27423			
MOTOR ASSY-REFRIGERANT	27433			
AIR PURIFIER COMP	27452			
DRAIN HOSE	27619			
EVAPORATOR	27621			
SWITCH-HIGH PRESSURE	27623			
EXPANSION VALVE	27625			
COMPRESSOR ASSY	27630			
RADIATOR FAN CONTROL	27631			
ELECTRIC A/C UNIT	27635			
REAR DEFROSTER	27640			
LOW PRESSURE SWITCH	27648			
CONDENSOR	27650			
CONDENSOR FAN & MOTOR	27651			
FAST IDLE DIAPHRAGM	27655			
SOLENOID VALVE	27659			
SUCTION THROTTLE VALVE	27660			
SWITCH-REAR A/C	27665			
SIDE VENT DUCT	27670			
ACCELERATION CUT SWITCH	27671			
COIL SPRING	27677			
O-RING SEAL	27680			
VACUUM LOCK-OUT SWITCH	27685			
FLOOR DUCT SENSOR	27700			
VENTILATOR DUCT SENSOR	27701			
DEFROSTER NOZZLE SENSOR	27702			
FOOT IN-CAR SENSOR	27703			
FOOT IN-CAR SENSOR	27704			
SUNLOAD SENSOR	27705			
SENSOR-CABLE	27706			
AIR PURIFIER SENSOR	27708			
SENSOR-REFRIGERANT TEMP, COMPRESSURE DISCHARGE	27710			
VACUUM HOSE	27711			
REAR AIR TEMP, PTH HEATER OUTLET	27712			
FAN CONTROL AMPLIFIER	27717			
AIR FAN SENSOR	27723			
ASPIRATOR	27726			
IN-VEHICLE SENSOR	27727			
DUCT - ASPIRATOR	27728			
COMPRESSOR SHAFT SEAL	27730			
WATER TEMP SENSOR	27732			
BV-LEVEL MOTOR ACTUATOR	27736			
FEEDBACK RESISTOR (PBR)	27738			
AIR MIX DOOR ACTUATOR	27740			
DOUBLE SOLENOID VACUUM VALVE	27741			
MAGNETIC CLUTCH	27742			
SNAP RING	27746			
ACTUATOR - VENTILATOR DOOR UPPER	27746			
ACTUATOR - DEFROSTER DOOR	27747			
ACTUATOR-DRIVER SIDE, AIR MIX DOOR	27748			
ACTUATOR-DRIVER SIDE, INTAKE DOOR	27749			
TRANSFORMER-POWER	27750			
ASPIRATOR FAN	27752			
AMBIENT SENSOR	27755			
SENSOR-AMBIENT AIR TEMP	27759			
AUTO TEMP CTRL UNIT	27762			
UNIT-CONTROL, HEAT PUMP	27763			
SUNLOAD SENSOR AMPLIFIER	27764			
SHIFT ACTUATOR VALVE	27765			
SOLENOID VALVE SET	27770			
AUTO AIR CONTROL AMPLIFIER	28520			
MAGNETIC CLUTCH AMPLIFIER	28525			
SEAL-CONDENSER SIDE	92184			
VALVE-EXPN	92200			
SENSOR HEAT SHUNT (REAR)	92316			
THERMAL PROTECTOR	92316			
ACCELERATION CUT TIMER	92350			
SUPER HEAT TIMER	92351			
HOSE ASSY HEATER	92400			
REAR WASHER TUBE	92401			
REAR HEATER HOSE	92420			
REAR HEATER HOSE	92423			
PIPE ASSY-FR COOLER, HIGH	92461			
REAR COOLER PIPE (REAR)	92460			
REAR COOLER ASSY (FRONT)	92462			
REAR HIGH/LOW COOLER PIPE	92470			
LOW PRESSURE FLEXIBLE HOSE	92480			
HIGH PRESSURE FLEXIBLE HOSE	92490			
HEATER PUMP ASSY	92516			
COMPRESSOR RPM NS	92855			
COMPRESSOR RPM NS	92805			

### AUDIO/VIDEO/NAVIGATION

Part Name	Part Number	COL D Preferred	SILVER Preferred	POWERTRAIN Preferred
DVD VIDEO CONSOLE	AA017			
MOBILE ENT SYS	AA018			
SATELLITE RADIO ANTENNA ASSY	AA025			
AU TUNING KIT	AA025			
HATCH AUDIO/COMBO UNIT	2790A			
HITCH CASSETTE DECK	2790B			
PANASONIC AUDIO/COMBO UNIT	2790C			
ELD (QUEST) RADIO/COMBO UNIT	2790F			
CLARION SPEAKER	2793A			
CLARION SPEAKER AMP	2806C			
ELD (QUEST)SPKR AMP	2806F			
SPEAKER - WOOFER	2806H			
PANASONIC (QST) SPKR AMP	2806P			
SONY SPKR AMP	2806S			
CLARION CD PLAYER	2818A			
PANASONIC CD PLAYER	2818C			
SONY CD PLAYER	2818D			
ALPINE CD PLAYER	2818E			
ELDS/DYCD PLAYER	2818F			
CLARION CASSETTE DECK	2920A			
HITCH CASSETTE DECK	2920B			
PANASONIC CASSETTE DECK	2920C			
CD CHANGER, CARTRIDGE	88118			
REAR MEDIA ANTENNA AMP	25198			
REAR MEDIA AMP	25198			
NAV SPEAKER RELAY	25273			
CONTROL ASSY-MASTER	25914			
NAV GPS ANTENNA ASSY	25957			
CABLE-GPS ANTENNA FEEDER	27931			
SPEAKER	27933			
SPEAKER - WOOFER	27934			
CABLE-AUX AUDIO SYSTEM	27946			
ANTENNA	27960			
CONSOLE	27984			
RADIO FINISHER	28041			
TUNE-ASSY - AV	28050			
POWER SUPPLY BOX	28089			
VIDEO ON NAVI DISPLAY ASSY	28090			
FES Video Monitor	28091			
DISPLAY ASSY-INTEGRATED	28094			
DVD UNIT	28119			
SWITCH ASSY-DISK EJECT	28123			
TWEETER-RDR DOOR	28128			
CHANGER-CD AUTO	28184			
ANTI-ASSY-SAT	28208			
ANTENNA RDR/MAST	28215			
SAT ANTENNA ASSY	28228			
FEEDER ASSY - ANTENNA	28243			
FEEDER ASSY (TEL ADPTR/BLUE TOOTH)-ANT	28245			
ANTENNA-ADAPTR	28247			
CONTROL PANEL-FES	28259			
REAR HEADPHONE	28267			
REMOTE RADIO SWITCH	28268			
PHONE-HEAD	28310			
UNIT-MICROPHONE MIXING	28312			
CONTROL ASSY-AUDIO VISUAL	28330			
CONTROL UNIT ASSY-DISPLAY	28332			
TRANSFER ASSY - NAVI	28344			
BONDING (GROUNDING) WIRE	28360			
SWITCH ASSY-ITS & AUDIO	28394			
NAV SWITCH ASSY	28397			
NAV SWITCH ASSY	28397			
CONTROL UNIT-AUX AUDIO SYSTEM	28413			
CONNECTOR-AUX AUDIO SYSTEM	28413			
AMP-HEADPHONE	28438			
FES Video Cassette Player	28706			
CASSETTE PLAYER/DECK	29000			
BALANCER-SOUND	29350			

### BRAKES

Part Name	Part Number	COL D Preferred	SILVER Preferred	POWERTRAIN Preferred
SENSOR ASSY - PRESS	22368			
SENSOR ASSY-VACUUM	22369			
TCS SWITCH ASSY	25145			
ABS MOTOR RELAY	25185			
VDC/TCS/ABS RELAY BOX	25285			
VDC/TCS/ABS CONTROL UNIT ASSY	25286			
TRIP RESET/IGNITOR RELAY	25320			
STOP TAMP SWITCH	25324			
BRAKE CONTROL MODULE	26354			
HAND BRAKE CONTROL	36010			
PARKING BRAKE SWITCH	36011			
PARKING ECU	36032			
PARKING BRAKE ACTUATOR ASSY	36035			
RATCHET NAIL	36320			
HAND BRAKE STEM	36327			
PARKING BRAKE RELEASE ROD	36328			
HAND BRAKE BRACKET	36335			
HAND BRAKE GUIDE	36335			
HAND BRAKE SPRING	36337			
HAND BRAKE CONTROL LEVER YOKE	36339			
HAND BRAKE LEVER	36372			
CLEVIS PIN (HAND BRAKE)	36381			
FRONT CABLE	36402			
CENTER LEVER BRACKET	36421			
ADJUSTER NUT	36427			
FRONT CABLE	36450			
CROSS CABLE	36452			
REAR CABLE/ROD	36452			
CENTER LEVER	36510			
EQUALIZER	36518			
HANGER STRAP/SWING ARM	36528			
CLEVIS & PIN (HAND BRAKE)	36535			
RETURN SPRING	36545			
REAR CABLE ADJUSTER	36547			
CABLE YOKE	41025			
HOLD DOWN PIN	41040			
PIVOT PIN	41041			
ANTI-SQUEAK SPRING	41086			
CLIP	41100			
FRONT CALPER	41120			
CALPER SEAL & PISTON	41151			
FRONT BAFFLE PLATE	44010			
REAR CALPER	44025			
CALPER BODY	44040			
HOLD DOWN PIN	44040			
EXTENSION LINK	44075			
ANTI-RATTLE PIN	44082			
HAND BRAKE CONTROL LVR YOKE	44082			
REAR BRAKE RETURN SPRING	44090			
TOGGLE LEVER	44095			
REAR WHEEL CYLINDER	44100			
LEVER ASSY	44118			
PISTON & SEAL	44120			
ANCHOR - PARKING BRAKE	44180			
ADJUST ASSY - BRAKE	44200			
MASTER CYLINDER	44601			
BRAKE STROKE SHIM CVL	44601			
OIL RESERVOIR CAP	46020			
RESERVOIR SEAL	46045			
LEVEL INDICATOR	46048			
PISTON ASSY	46063			
SNAP RING	46082			
FLUID RESERVOIR	46090			
FLUID STRAINER	46093			
FRONT HOSE	46113			
CLEVIS PIN	46123			
REAR BRAKE HOSE	46201			
REAR BRAKE HOSE	46211			
BRAKE TUBE CONNECTOR - TYPE 2A	46220			
BRAKE PIPE	46284			
REAR CENTER BRAKE HOSE	46310			
CONNECTOR	46313			
DR/LOAD SENSING VALVE	46400			
PROPORTIONING VALVE	46401			
AUTO ADJUSTING BRAKE PEDAL	46405			
BRAKE MASTER CYLINDER BRACKET	46518			
PEDAL STOPPER	46520			

		COLD Preferred	SILVER Preferred	POWERTRAIN Preferred
IDLE COMPENSATOR	16351			
THERMO ELEMENT KIT	16391			
INJECTION HOSE	16409			
SENSOR WATER DETECTOR	16412			
COVER-PLATE/GASKET	16420			
FUEL RAIL CROSSOVER TUBE	16441			
HOSE ASSY-FUEL RETURN/TO ENGINE	16446			
SEPARATOR ASSY OIL AIR	16480			
AIR CLEANER ASSY	16500			
VACUUM MOTOR ASSY	16510			
IDLE COMPENSATOR TUBE	16520			
AIR CLEANER INSULATOR	16523			
AIR HOSE	16579			
AIR TEMP SENSOR	16580			
RESONATOR	16585			
FUEL INJECTOR	16603			
VALVE-FUEL PRESSURE RELIEF	16614			
SUPPLY LINE-FUEL PUMP	16615			
RETURN LINE-FUEL PUMP	16616			
SUPPLY LINE-FUEL RAIL	16617			
RETURN LINE-FUEL RAIL	16618			
PUMP ASSY-HIGH PRESSURE, FUEL	16632			
FUEL PRESSURE SENSOR	16637			
SENSOR ASSY-FUEL PRESSURE	16638			
SUPPLY LINE-HIGH PRESSURE, FUEL RAIL	16685			
BELT TENSIONER	16805			
OIL TEMP SENSOR	16970			
FUEL PUMP CONTROL UNIT	17001			
FUEL PUMP REPAIR KIT	17010			
ELECTRIC FUEL PUMP	17012			
FUEL PUMP CHECK VALVE	17014			
FUEL PUMP GASKET	17099			
FUEL CONNECTOR	17103			
FUEL TANK	17201			
TUBE ASSY FILLER	17220			
FUEL FILLER NECK	17222			
FUEL FILLER CAP	17251			
FUEL (HOSE) PROTECTOR	17271			
FUEL TANK PROTECTOR	17285			
EC-HOSE PROTECTOR	17325			
FUEL CHECK VALVE	17330			
BREATHER TUBE KIT	17331			
EC-VENTILATION HOSE	17333			
EC-VAPOR VENT HOSE	17337			
FUEL BREATHER TUBE	17338			
O-RING	17342			
BREATHER VALVE	17368			
FUEL PIPE BREATHER VLV	17369			
VALVE ASSY FUEL CHECK	17370			
EVAPORATOR SHUT-OFF VALVE	17371			
VACUUM CUT VALVE	17372			
EFI BCDD ASSY	17484			
FUEL OUTLET TUBE	17501			
VAPOR VENT LINE	17508			
FUEL RETURN TUBE	17510			
FRONT FUEL TUBE	17520			
RAIL-COMMON	17521			
HIGH PRESSURE FUEL TUBE ASSY	17522			
TUBE-FUEL TANK FUEL SUPPLY	17701			
TUBE-FUEL TANK FUEL RETURN	17702			
AUTO-ADJUSTING ACCCEL PEDAL	18002			
ACTUATOR-ACCELERATOR PEDAL	18006			
ACCELERATOR ARM	18010			
ACCELERATOR BRACKET	18021			
PEDAL STOPPER BRACKET	18050			
ACCELERATOR PEDAL	18110			
ACCELERATOR WIRE	18150			
RETURN SPRING	18215			
EC-TUBE & HOSE	18721			
SEPARATOR ASSY-WATER	18793			
WATER SEPARATOR	18795			
FRONT EXHAUST GASKET	20711			
CONVERTER GASKET	20712			
EXHAUST MANIFOLD/CATALYTIC CONVERTER	20801			
WATER PUMP	21010			
WATER PUMP HOUSING AND GASKET	21012			
WATER PUMP GASKET	21014			
FAN PULLEY BRACKET	21046			
INTAKE MANIFOLD CONNECTOR & O-RING	21049			
WATER PUMP/FAN PULLEY	21051			
FAN BLADE	21060			
MOTOR & FAN ASSY (WITH SHROUD)	21066			
FAN COUPLING ASSY	21082			
THERMOSTAT	21200			
OIL COOLER PIPE	21302			
OIL COOLER-FIN TYPE	21305			
OIL COOLER RADIATOR TYPE	21306			
OIL COOLER GASKET	21310			
PT-OIL COOLER HOSE	21355			
OIL COOLER WATER HOSE	21380			
RADIATOR	21400			
RADIATOR CAP	21430			
AIR GUIDE	21468			
RADIATOR SHROUD	21475			
RADIATOR DRAIN COCK	21480			
HOSE-MOTOR INLET	21500			
UPPER RADIATOR HOSE	21501			
UPPER RAD SUB HOSE	21502			
LOWER RADIATOR HOSE	21503			
SUB RADIATOR PIPES/HOSES	21504			
HEV UNIT WATER HOSE	21505			
PUMP HOSE ASSY	21507			
CONVERTER HOSE ASSY	21508			
RESERVOIR TANK	21510			
RESERVOIR TANK BRACKET	21511			
SUB RAD RESERVOIR TANK	21512			
PIPE ASSY-CONVERTER INLET	21513			
HOSE-CONVERTER OUTLET	21514			
RESERVOIR TANK HOSE	21515			
PIPE ASSY-CONVERTER INLET	21516			
PUMP HOSE ASSY	21517			
HOSE INVERTER OUTLET	21534			
PIPE-PUMP INLET	21537			
ELECTRIC WATER PUMP	21580			
MOTOR ASSY WATER PUMP	21581			
THERMO SWITCH	21595			
RADIATOR FAN MOTOR	21597			
A/T OIL COOLER ASSY	21606			
OIL COOLER VALVE ASSY	21619			
TUBE ASSY	21620			
OIL COOLER VALVE ASSY	21630			
OIL COOLER HOSE	21631			
OIL COOLER PIPING	21636			
TRANSISTOR IGNITION UNIT	22020			
DISTRIBUTOR	22100			
SHAFT	22108			
RELUCTOR	22115			
GOVERNOR WEIGHT	22127			
DISTRIBUTOR PINION	22129			
DISTRIBUTOR CAM	22132			
ROTOR HEAD	22157			
MAGNET	22158			
HARNESS	22159			
DISTRIBUTOR CAP	22162			
STATOR	22163			
DISTRIBUTOR PROTECTOR	22172			
VACUUM GALLERY	22310			
VIA5 VENT HOSE	22320			
SENSOR-TEMPERATURE, CHARGE AIR COOLER	22350			
OUTLET PRESSURE	22351			
SENSOR-TEMPERATURE, CHARGE AIR COOLER	22351			
OUTLET	22351			
BOOST SENSOR	22364			
ABSOLUTE PRESSURE SENSOR	22366			
IGNITION COIL/PWR TRANSISTOR	22433			
HIGH TENSION CABLE	22460			
RESISTOR	22462			
IGNITION COIL PROTECTOR	22465			
AIR CURT VALVE	22622			
SCV SENSOR ASST	22623			
FUEL TEMP SENSOR	22629			
TANK FUEL TEMPERATURE SENSOR	22634			
FUEL DAMPER	22675			
AIR FUEL RATIO SENSOR	22689			
ECC MAIN RELAY	22696			
DROPPING RESISTOR	22698			
ALTERNATOR	23100			
ALTERNATOR ROTOR	23108			
ALTERNATOR BEARING	23120			
ALTERNATOR BRUSH & HOLDER	23133			
ALTERNATOR PULLEY	23150			
ALTERNATOR PULLEY & HOLDER	23153			
IC VOLTAGE REGULATOR	23215			
DIODE SET	23230			
STARTER MOTOR ASSY	23300			
FIELD COIL	23306			
ARMATURE	23310			
CLUTCH PINION	23312			
REDUCTION GEAR	23313			
STARTER SOLENOID	23343			
BRUSH	23380			
HYBRID VEH CNTRL (ECU)	23700			
CRANKSHAFT POS. SENSOR (OBD POS)	23731			
CRANKSHAFT POS. SENSOR (REF)	23732			
UNIT-PCM CONTROL	23740			
VVL ACTUATOR ASSY	23745			
IVTC POSITION SENSOR NS	23750			
MOTOR ASSY - ACTUATOR	23753			
CONTROL UNIT-ELECTRIC VALVE TIMING	23754			
VTC-ELECTRIC	23756			
MODULE-VCR CONTROL	23780			
VTC SOLENOID ASSY	23796			
ENGINE SUB HARNESS	24079			
BATTERY CABLE	24110			
BATTERY VENT TUBE	24413			
BATTERY VENT TUBE	24414			
BATTERY FRAME/TRAY/ROD	24428			
FUEL TANK SENSOR	25060			
COOLANT TEMP SENSOR	25080			
SENSOR-WATER LEVEL	25083			
BOOST SENSOR	25085			
EVAP CONTROL SYST PRESS SENSOR	25086			
FUEL CUT OFF SWITCH	25146			
THROTTLE MOTOR RELAY	25171			
RELAY-ENGINE RESTART	25178			
RELAY-ENGINE RESTART BYPASS CONTROL	25179			
RADIATOR FAN RELAY	25217			
RELAY	25230			
OIL PRESSURE SENDING UNIT	25240			
OIL PRESSURE SWITCH	25244			
COOLING FAN CONTROL	25305			
22I-WATER CONTROL COCK	27117			
FLYWHEEL HOUSING NS	32040			
TRANSMISSION CONTROL MDL NS	32085			
PLUG ASSY-DRAIN	32101			
PLUG ASSY-DRAIN	32111			
PRESSURE TUBE	45455			
QUICK CONNECTOR ASSY AIR PRESSURE TUBE	45456			
SENSOR-TURBOCHARGER SPEED	59126			
BRACKET ASSY-CHARGE PORT	62551			
ENGINE MOUNTING BRACKET	75117			
ADAPTER-FILTER HEAD	78323			
VACUUM HOSE	90004			
VALVE ASSY WATER	92231			
TUBE-BOOST SENSOR	97195			

		COLD Preferred	SILVER Preferred	POWERTRAIN Preferred
EGR TUBE	14120			
POWER VALVE ASSY	14510			
POWER VALVE SOLENOID VALVE ASSY	14517			
POWER VALVE ACTUATOR	14518			
EGR CONTROL VALVE	14710			
ECR PASSAGE	14711			
EC-EGR VACUUM HOSE	14729			
EXHAUST TEMP SENSOR	14730			
BBT VALVE	14741			
A.I.V. UNIT CASE	14810			
PUMP ASSY-AIR	14812			
A.I.V. TUBE	14821			
AIR INJECTION PIPE	14823			
VALVE ASSY-AIR CVT SOLENOID	14830			
AIR CONTROL VALVE	14832			
A.B. VALVE	14834			
AIR INJECTION VALVE	14854			
HOSE ASSY-AIR	14858			
EC-HOSE	14860			
CONNECTOR-HOSE, 3WAY	14877			
CONNECTOR-HOSE	14879			
A.I.V. BOX	14910			
TUBE-EVAP CONTROL	14912			
SERVICE PORT-EVAP	14939			
SCV SOLENOID VALVE	14951			
POWER VALVE SOLENOID	14952			
EGR SOLENOID VALVE	14954			
VACUUM CUT SOLENOID	14955			

		COLD Preferred	SILVER Preferred	POWERTRAIN Preferred
EGR MIXTURE SOLENOID	14956			
SPARK DELAY VALVE	14958			
PRESSURE REG. CONTROL	14960			
ALTITUDE SWITCH	16044			
DASH POT	16182			
I.A.S. UNIT	16250			
PROTECTOR-FUEL RAIL, D-INU HIGH PRESSURE	16245			
THROTTLE CHAMBER	17118			
PROTECTOR-FUEL RAIL	17524			
DETONATION SENSOR	22060			
EGR WATER TEMP SENSOR	22120			
VACUUM TANK	22327			
VIA5 VACUUM TANK ASSY	22328			
CK SWITCH-CANISTER VAC CNTRL	22360			
VACUUM SWITCH	22361			
EGR VACUUM CONTROL VALVE	22365			
CONTROL UNIT - EFI	22611			
THROTTLE VALVE SWITCH	22620			
WATER TEMP SENSOR	22630			
AIR TEMPERATURE SENSOR	22631			
CYLINDER HEAD TEMP SENSOR	22632			
AIR REGULATOR	22660			
PRESSURE REGULATOR	22670			
PRESSURE REG. CONTROL MODULE	22671			
AIR FLOW METER	22680			
AIR FLOW METER BRACKET	22682			
VACUUM CONTROL VALVE	22686			
O2 SENSOR	22690			
REAR OXYGEN O2 SENSOR	22691			
DROPPING RESISTOR	22695			
MAIN & FUEL PUMP RELAY	22697			
CRANK ANGLE SENSOR	23730			
CRANK POSITION SENSOR-RING GEAR	23733			
A.A.C. VALVE	23781			
EFI HARNESS	24011			
EGR CONTROL UNIT	25024			
SOLENOID-COMPRESSOR BYPASS VALVE	25679			
EGR RESERVOIR TANK	27085			
BASE ASSY-FUEL FILLER	78120			
FUELING STOPPER ASSY	78402			
HOUSING-STAGE2, FUEL FILTER	78507			
HOUSING-FUEL FILTER	78509			

## STEERING

		COLD Preferred	SILVER Preferred	POWERTRAIN Preferred
IDLER PULLEY BRACKET	11935			
POWER STEERING PUMP BRACKET	11940			
ADJUSTING BAR	11945			
LAMP - HICAS WARNING	25520			
HICAS RELAY	25247			
SLIP RING	25694			
STEERING SENSOR ASSY	28475			
HICAS CONTROL UNIT	28505			
STEERING STOPPER PLATE	40040			
RACK & PINION ASSY	48001			
STEERING GEAR HOUSING	48011			
STEERING GEAR PINION	48023			
WORM GEAR BEARING	48025			
FILLER PLUG	48061			
UPPER STEERING JOINT ASSY	48070			
STEERING LOWER JOINT	48080			
STEERING RACK	48100			
SECTOR SHAFT	48103			
WORM OIL SEAL	48125			
SECTOR SHAFT BEARING	48127			
SECTOR SHAFT ADJUST SCREW/NUT	48135			
SECTOR SHAFT OIL SEAL	48137			
STEERING WORM ASSY	48150			
SECTOR SHAFT COVER	48201			
STEERING GEAR BOOT	48203			
SECTOR SHAFT COVER GASKET	48204			
REAR HOUSING	48210			
REAR HOUSING CAP	48212			
REAR HOUSING OIL SEAL	48214			
ADJUSTER	48231			
RACK MOUNT CLAMP	48353			
RACK MOUNT INSULATOR	483			